

Technical Data

Light fitting for indoor use only
Power Factor: 1
Powers:

Driver 40W - Input wattage 46W

It is recommended that a professional electrician be responsible for installing the light.

Warning: If the wire or flexible cord is damaged, it must only be changed by the manufacturer, their Service Dept. or qualified personnel in order to avoid risk.

Cleaning Instructions

Use a soft damp cloth, with soap or neutral detergent. Do not use alcohol or other solvents.

Datos Técnicos

Luminaria para uso interior
Factor de Potencia: 1
Potencias:

Driver 40W - Input wattage 46W

Se recomienda que la instalación sea realizada por un profesional.

Aviso: Si el cable flexible o cordón de esta luminaria está dañado, deberá sustituirse exclusivamente por el fabricante o su servicio técnico o una persona de cualificación equivalente con objeto de evitar cualquier riesgo.

Instrucciones para la limpieza

Utilizar un paño suave, humedecido con agua y detergente neutro si fuera necesario. No utilizar alcohol o otros disolventes.

Dry location only



This symbol on the product or its packaging indicates that it must not be treated as household waste. It should, in fact, be handed in at a recognised collection point for recycling electrical and electronic equipment. For more detailed information about the recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

Este símbolo en su equipo o embalaje indica que el presente producto no puede ser tratado como residuo doméstico normal, sino que debe entregarse en el correspondiente punto de recogida de equipos eléctricos y electrónicos. Para recibir información detallada sobre el reciclaje de este producto, por favor, contacte con su ayuntamiento, su punto de recogida más cercano o el distribuidor donde adquirió el producto.

Dimmer


120-270 V - 50/60 Hz

marset




NENÚFAR

Canopy 40W Hi-Lume dimmable / *Florón 40W Hi-Lume dimable*

Assembly Instructions / Instrucciones de Montaje



marset



Warning!

Disconnect power supply before installation.

Atención!

Desconectar la conexión a red antes de ser manipulada.

1. Remove the cover (A).
2. Remove the nuts (B) to separate the tray with the LED driver from the canopy.
3. Make electrical connections into the outlet box. Fix the canopy (C) to the outlet box.
4. Place again the tray and fix it with the nuts (B).
5. Pass the cables for each Nenúfar element through the strain relieves (D). Tighten the strain relief screw using the Allen Key. Connect the red (or blue) wire to the positive (+) terminal and the black (or brown) to the negative (-) terminal.
6. Re-attach the cover (A) using the small screws provided.

1. Quitar la tapa (A) del florón .
2. Quitar las tuercas (B) y separar la bandeja con el equipo electrónico.
3. Hacer las conexiones eléctricas en la caja de empalmes. Fijar el florón (C) en la caja de empalmes.
4. Fijar de nuevo la bandeja con las tuercas (B)
5. Pasar el cable de cada Nenúfar a través de los prensacables (D). Apretar el tornillo del prensacables utilizando la llave suministrada. Conectar el cable Rojo (o Azul) en el borne (+) y el cable Negro (o Marrón) en el borne (-).
6. Fijar la tapa (A) de nuevo utilizando los tornillos suministrados.