

#### Technical Data

Light fitting for indoor use only

Power Factor: 1

Bulb to be used:

E26 TYPE A 60W 

E26 CFL TYPE T 18W 

E26 LED TYPE A 11W 

It is recommended that a professional electrician be responsible for installing the light.

**Warning:** If the wire or flexible cord is damaged, it must only be changed by the manufacturer, their Service Dept. or qualified personnel in order to avoid risk.

#### Cleaning Instructions

It is recommended to use a hair dryer or a clean brush to remove dust from the surface.

#### Datos Técnicos

Luminaria para uso interior

Factor de Potencia: 1

Lámpara a utilizar:

E26 TYPE A 60W 

E26 CFL TYPE T 18W 

E26 LED TYPE A 11W 

*Se recomienda que la instalación sea realizada por un profesional.*

**Aviso:** Si el cable flexible o cordón de esta luminaria está dañado, deberá sustituirse exclusivamente por el fabricante o su servicio técnico o una persona de cualificación equivalente con objeto de evitar cualquier riesgo.

#### Instrucciones para la limpieza

*Se recomienda limpiar con aire. Se puede utilizar un secador de pelo. También es posible realizar la limpieza con un cepillo limpio.*

#### Dry location only



This symbol on the product or its packaging indicates that it must not be treated as household waste. It should, in fact, be handed in at a recognised collection point for recycling electrical and electronic equipment. For more detailed information about the recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.


*Este símbolo en su equipo o embalaje indica que el presente producto no puede ser tratado como residuo doméstico normal, sino que debe entregarse en el correspondiente punto de recogida de equipos eléctricos y electrónicos. Para recibir información detallada sobre el reciclaje de este producto, por favor, contacte con su ayuntamiento, su punto de recogida más cercano o el distribuidor donde adquirió el producto.*

120 V - 60 Hz


**marset** 

# SCOTCH CLUB 41

Assembly Instructions / Instrucciones de Montaje



**marset**



### IMPORTANT SAFETY INSTRUCTIONS:

1. Read all instructions completely before beginning installation. Keep these instructions in a safe place for future reference.
2. To reduce risk of fire and over-heating, make sure all connections are tight.
3. Connect this product only to a 120V 60 Hz electrical supply.

### Warning!

Disconnect power supply before installation and change the bulb only when cold.

### Atención!

Desconectar la conexión a red antes de ser manipulada y realizar el cambio de bombilla sólo cuando ésta se haya enfriado.

1. Introduce the electric wire (C) and the steel take-up (D) up through the inside of the ceramic shade (E).
2. Pass the wire through the slack adjuster (F) and the steel take-up through the governor (G) in the ceiling rose (H).
3. Connect the wiring in the outlet box. Fix ceiling plate (A) to the outlet box using screws (B).
4. Hang the light and adjust its height by passing the steel take-up through the second governor (I) and closing it.
5. Raise the ceiling rose (H) and immobilise it by means of the governor (G). Fully tighten slack adjuster (F).
6. Insert an approved bulb.
7. Position clamp (K) to attach the electric wire to the steel take-up.

1. Introducir el cable (C) y el tensor de acero (D) por el interior de la pantalla cerámica (E).
2. Pasar el cable por el prensacables (F) y el tensor de acero por el regulador (G) del florón (H).
3. Realizar las conexiones eléctricas en la caja de empalmes. Fijar el soporte (A) en la caja de empalmes mediante los tornillos (B).
4. Suspender la lámpara y regular su altura pasando el cable de acero por el regulador (I).
5. Subir el florón e inmovilizarlo utilizando el regulador (G).- Atornillar el prensacables (F).
6. Colocar la bombilla recomendada.
7. Colocar la abrazadera (K) para fijar el cable eléctrico con el cable de acero.