

Technical Data

Light fitting for outdoor use only

Power Factor: 1

Bulb to be used:

Soho 57 IP44

C-T5 2GX13 22W+40W ○

Soho 112 IP44

8 x T5 HO Mini Bipin 24W ⇐⇒

It is recommended that a professional electrician be responsible for installing the light.

Warning: If the wire or flexible cord is damaged, it must only be changed by the manufacturer, their Service Dept. or qualified personnel in order to avoid risk.

Cleaning Instructions

Use a soft damp cloth, with soap or neutral detergent. Do not use alcohol or other solvents.

Datos Técnicos

Luminaria para uso exterior

Factor de Potencia: 1

Lámpara a utilizar:

Soho 57 IP44

C-T5 2GX13 22W+40W ○

Soho 112 IP44

8 x T5 HO Mini Bipin 24W ⇐⇒

Se recomienda que la instalación sea realizada por un profesional.

Aviso: Si el cable flexible o cordón de esta luminaria está dañado, deberá sustituirse exclusivamente por el fabricante o su servicio técnico o una persona de cualificación equivalente con objeto de evitar cualquier riesgo.

Instrucciones para la limpieza

Utilizar un paño suave, humedecido con agua y detergente neutro si fuera necesario. No utilizar alcohol o otros disolventes.

Suitable for wet locations



This symbol on the product or its packaging indicates that it must not be treated as household waste. It should, in fact, be handed in at a recognised collection point for recycling electrical and electronic equipment. For more detailed information about the recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.


Este símbolo en su equipo o embalaje indica que el presente producto no puede ser tratado como residuo doméstico normal, sino que debe entregarse en el correspondiente punto de recogida de equipos eléctricos y electrónicos. Para recibir información detallada sobre el reciclaje de este producto, por favor, contacte con su ayuntamiento, su punto de recogida más cercano o el distribuidor donde adquirió el producto.

120 V - 60 Hz


marset c  **us**

SOHO 57 & 112 IP44

Assembly Instructions / Instrucciones de Montaje



marset



IMPORTANT SAFETY INSTRUCTIONS:

1. Read all instructions completely before beginning installation. Keep these instructions in a safe place for future reference.
2. To reduce risk of fire and over-heating, make sure all connections are tight.
3. Connect this product only to a 120V 60 Hz electrical supply.

Warning!

Disconnect power supply before installation and change the bulb only when cold.

Atención!

Desconectar la conexión a red antes de ser manipulada y realizar el cambio de bombilla sólo cuando ésta se haya enfriado.

1. Fasten the cable gliders (A) by means of the specific nuts and bolts, using the template supplied to position them correctly.
2. Hang the lampshade at the desired height by passing the steel wires (D) through the cable gliders (E). Remove any excess wire with wirecutters. Pass the electrical cable (F) through the cable gland in the ceiling rose (G). Connect the wiring in the outlet box. Fix the ceiling plate (B) to the outlet box using the screws (C). Secure the electrical cable by means of the cable clamp (H). Attach the ceiling rose (G) using the screws provided (I).



Attention: Use silicone to seal the rose to the ceiling.

3. Use the clip (J) to tie the electric cable to the steel wire.
4. Insert approved bulbs and attach the diffuser (K) screwing up piece (L).

1. Fijar los suspendores (A) mediante los tornillos y tacos suministrados. Utilizar la plantilla suministrada para posicionarlos.
2. Suspender la pantalla de la lámpara a la altura deseada pasando los cables de acero (D) a través de los suspendores (E). Cortar el exceso de cable con unos alicates de corte. Pasar el cable eléctrico (F) a través del prensaestopas del florón (G). Realizar las conexiones eléctricas en la caja de empalmes. Fijar el soporte (B) a la caja de empalmes utilizando los tornillos (C). Asegurar el cable eléctrico utilizando el prensacables (H). Fijar el florón (G) mediante los tornillos suministrados (I).



Atención: Siliconar el florón al techo

3. Colocar la abrazadera (J) para fijar el cable eléctrico con el cable de acero.
4. Colocar las bombillas recomendadas y fijar el difusor (K) roscando la pieza (L).