




Technical Data

Light fitting for indoor use only
Power Factor: 1
Bulb to be used:

- 2 x E26 TYPE A19 60W 
- 2 x E26 CFL TYPE T 20W 
- 2 x E26 LED TYPE A 11W 

It is recommended that a professional electrician be responsible for installing the light.




Warning: If the wire or flexible cord is damaged, it must only be changed by the manufacturer, their Service Dept. or qualified personnel in order to avoid risk.

Cleaning Instructions

Use a soft damp cloth, with soap or neutral detergent. Do not use alcohol or other solvents.

Datos Técnicos

Luminaria para uso interior
Factor de Potencia: 1
Lámpara a utilizar:

- 2 x E26 TYPE A19 60W 
- 2 x E26 CFL TYPE T 20W 
- 2 x E26 LED TYPE A 11W 

Se recomienda que la instalación sea realizada por un profesional.

Aviso: Si el cable flexible o cordón de esta luminaria esta dañado, deberá sustituirse exclusivamente por el fabricante o su servicio técnico o una persona de cualificación equivalente con objeto de evitar cualquier riesgo.

Instrucciones para la limpieza

Utilizar un paño suave, humedecido con agua y detergente neutro si fuera necesario. No utilizar alcohol o otros disolventes.

Dry location only



This symbol on the product or its packaging indicates that it must not be treated as household waste. It should, in fact, be handed in at a recognised collection point for recycling electrical and electronic equipment. For more detailed information about the recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.


Este símbolo en su equipo o embalaje indica que el presente producto no puede ser tratado como residuo doméstico normal, sino que debe entregarse en el correspondiente punto de recogida de equipos eléctricos y electrónicos. Para recibir información detallada sobre el reciclaje de este producto, por favor, contacte con su ayuntamiento, su punto de recogida más cercano o el distribuidor donde adquirió el producto.

120 V - 60 Hz


marset 

MERCER C

Assembly Instructions / Instrucciones de Montaje



marset



IMPORTANT SAFETY INSTRUCTIONS:

1. Read all instructions completely before beginning installation. Keep these instructions in a safe place for future reference.
 2. To reduce risk of fire and over-heating, make sure all connections are tight.
 3. Connect this product only to a 120V 60 Hz electrical supply.
-

Warning!

Disconnect power supply before installation and change the bulb only when cold.

Atención!

Desconectar la conexión a red antes de ser manipulada y realizar el cambio de bombilla sólo cuando ésta se haya enfriado.

1. Connect the wiring in the outlet box.
2. Fix ceiling plate (A) and glass (B) to the outlet box using the screws (C).
3. Fix unit (D) using the nuts (E) provided.
4. Fit approved bulbs
5. Attach the diffuser (F) screwing up piece (G).

1. Realizar las conexiones eléctricas en la caja de empalmes.
2. Fijar el soporte (A) junto con el cristal (B) en la caja de empalmes mediante los tornillos (C).
3. Fijar el conjunto (D) mediante las tuercas (E) suministradas.
4. Colocar las bombillas recomendadas
5. Fijar el difusor (F) roscando la pieza (G).